




Kseibi 20V Max Cordless Mini Chainsaw 10cm Bare Unit

Compact cordless cutting for quick garden jobs

Kseibi · 710280

Highlights

- 20V Max cordless mini chainsaw for portable cutting
- 10 cm bar suits pruning and light trimming tasks
- 4 m/s chain speed for efficient everyday use
- Bare unit supplied without battery or charger
- Compact body helps with controlled handling
- Cordless design gives freedom to move around jobs
- Ideal for garden maintenance and small timber cuts
- Slim grip shape supports comfortable use
- Protective upper guard is visible on the tool
- Good choice for users already on a 20V Max system

Key Features

- Compact 10 cm bar — The 10 cm bar length is suited to pruning, trimming and other light cutting jobs where control matters.
- 20V Max cordless power — Cordless operation lets you work without trailing cables, making outdoor and around-property tasks easier to manage.
- 4 m/s chain speed — A 4 m/s chain speed helps deliver smooth, efficient cutting performance for routine maintenance work.
- Bare unit format — Supplied without battery and charger, this version is ideal if you already use compatible 20V Max equipment.
- Easy-to-handle design — The compact body and visible grip shape support manoeuvrability in tighter spaces and quick cutting tasks.

Specifications

Colour	Black and orange
Visible accessory	Oil bottle included in image

Specifications by Variant

Specification	710280
Voltage	20 V Max
Bar length	10 cm
Chain speed	4 m/s
Battery	Bare only without battery and charger